

54299 / RF1420X1

Position	ItemNo	Description
02	54665	Upper Hinge Left
03	54666	Front Panel Bracket
04	66907	Thermostat Carel IJFPSA4B06S0060
05	54667	Lock
06	54077	Door Switch
07	55013	Front Panel
08	12870	Hinge For Front Panel
09	54690	Back Bridge
10	54669	Water Box Cover
11	54670	Water Box
	54671	Discharge Pipe
13	54672	Discharge Pipe Clip
14	34481	Drain Pipe Cover
15	12937	Spring Hinge
16	54693	Gasket
17	55012	Door
18	54766	Down Hinge Axis Jacket
19	54695	Middle shelf
20	54696	Back Support
21	54674	Shelf
22	55820	Guide left
23	55821	Guide right
25	54697	Bottom Shelf Side
26	54698	Front Support
27	54699	Bottom Shelf Middle
28	54700	Door Post
29	54701	Cap for Door Post
30	32784	Braked Castors
31	32783	Standard Castors
33	55822	Air Conductor
34	54703	Inside Panel Left
35	54704	Inside Panel Right
36	54705	Evaporator Water Pan
37	54706	Water Pan Heater
38	54688	Drain Pipe Heater
39	13284	Protector
40	54707	Defrost Heater
43	54089	Internal Water Pipe
44	48148	Drain Pipe Nut
45	54709	Fan Support
46	32425	Evaporator Fan 12 VDC
47	54710	Fan Cover
48	32023	Sensor Clip For CK-I
49	54681	Water Pipe
51	33015	Fan Power Supply 12VDC 8 W
52	54711	Suction Pipe
53	54712	Condenser
54	32578	Condenser Fan Blade
55	54683	Condenser Fan
56	54684	Basket Guard
57	67540	Compressor
60	54686	Upper Hinge Right
61	54687	LED Light
62	67894	Foot pedal right
63	67895	Foot pedal left

54299 / RF1420X1

