

47447 / PC1250B

---

Position	ItemNo	Description
00	52041	Light Switch Green
08	47562	Door Gasket Long
09	47563	Door Gasket Short
10	52807	Door Handle Black
12	52808	Glass Door w/ Black Handle
13	47564	Door Gasket Long
14	52809	Side Panel Right, Black RAL9005
16	52811	Side Glass
17	52812	Front Grill, Black RAL9005
18	47565	Digital Thermostat Carel
22	52804	LED Driver
23	52806	Relay
24	47638	LED Driver
25	47579	Condenser
27	46053	Fan Blade
28	47569	Fan Motor
29	47820	Compressor
30	47581	Condenser
31	47582	Drip Tray
32	47583	Filter Drier
33	47584	Door Stopper
35	47585	Door Spring Stopper
36	47586	Door Spring
37	47571	Door Spring Right
	47572	Door Spring Left
41	47587	Castors
	47616	Legs
43	52810	Side Panel Left, Black RAL9005
45	47589	Bottom Shelf
46	47590	Evaporator
47	47591	Shelf Bracket
48	47573	LED Light
49	47592	Price Holder 40mm
	52815	Price Holder
51	47593	Shelf

47447 / PC1250B

